


Entrypoint installation guide




1



Unpack the unit.


2



Mount the rack ears and/or rubber feet, if applicable, and turn the unit back on its feet or mount it in the rack.


TANDBERG recommends that this product is mounted in the rack using additional support accessories like rack side support angles (rack angle brackets) or rack shelves due to its weight and depth. Please contact your rack supplier to request the accessories best fitted for your rack.

3




Depending on version, connect the PR1 connector...

4




... or connect the 4 BRI connectors.

5



Connect the Ethernet LAN cable to socket LAN 1. Connect the null modem cable between the Data socket and a PC.

6



Connect the power cable and turn on the unit. Use the LCD display of the unit to set the IP address – see *Configuring the Entrypoint* in the User Guide for details, or...

7



Start a Terminal program on the PC and configure it to 115200, 8, 1, None

8

Now, on the PC:

1. When prompted for login, enter username `admin` and password `TANDBERG`.
2. Type `y` to start the installation wizard and press Enter.
3. When prompted, specify a new password, IP settings, local prefix, SSH `y/n`, and Telnet `y/n`.
4. When prompted for login, enter username `admin` and your new password.
5. Press Enter to skip the installation wizard.
6. Reboot the system by typing the command `xcommand boot`